

Product Data and Installation Instructions

KeedeLath™

A Self-Furring Synthetic Lath

Description

KeedeLath™ is a self-furring synthetic lath that is easier to install and a lighter alternative to self-furred metal lath. The unique patented design replaces old metal lath in a variety of wall applications. This lath is constructed of entangled nylon mono-filaments incorporated into a fiberglass grid. The technology creates an easy to handle, durable and non-corroding reinforcement material.

Applications

- ✓ Stucco
- ✓ Manufactured Stone Veneers
- ✓ Thin Stone Veneers

Features and Benefits

Replaces traditional metal lath

Lightweight and easy to handle

Self-furring

Nylon core is resistant to most known corrosive chemicals, including solvents

Non-Corroding

Flexible and lays flat

High strength

Creates mechanical bond

Installs quicker than metal lath

Installation Instructions

Prior to Installation: Inspect Wall Conditions and Weather Barrier/Building Wrap

Ensure that the wall is free from structural defects, any membranes or flashing are properly installed, and the final system will have a path for moisture to escape from the wall. KeedeLath™ should only be applied to structurally sound surfaces, incorporate good building practices, and meet all local code requirements. Before starting any applications, check with your local building code requirements and read all manufacturers' installation instructions for exterior claddings or floor finish.

Product Selection

- Exterior cement plaster stucco
- Thin veneer and manufactured stone
- **KeedeLath™ is a replacement for standard metal lath in veneer applications**

Limitations

- Not intended for use on open framing and soffit conditions
- Maximum weight of exterior veneer 25 lbs per sq/ft

Installation Guide

1. Install per drawings, specifications and local building codes trim accessories.
2. Apply KeedeLath™ according to ASTM C1063, the standard to install lathing materials.
3. Roll out KeedeLath™ over substrate with plastic nubs facing inward. Product should be applied free of waves, bubbles and wrinkles. KeedeLath™ can be installed horizontally or vertically with a minimum overlap of 1-inch on all seems, as well as integrated with all trim accessories.
4. Use corrosion resistant fasteners to fasten and secure lath as referred to ASTM C1063 and local building codes. Install fastener every 6-inch o.c. vertically and 16-inch o.c. horizontally. Additional fasteners can attach the KeedeLath™ into the sheathing or framing prior to application of exterior veneer.
5. Install exterior cement plaster stucco and/or thin veneer or manufactured stone.

Packaging

Description	Means of Measurement English	Value English
Core Width	Inches	48.0
Length	Feet	25.0
Area	Square Feet	100
Roll Diameter	Inches	9.0
Roll Weight	Pounds	11

LIMITED WARRANTY: Keene Building Products, Inc. warrants to the initial purchaser only that the goods sold hereunder will be free from defects in material and workmanship and, except as otherwise set forth herein, will conform to the specifications provided. If any failure to meet this warranty appears within one year from the date of shipment of the goods, on the condition that Keene Building Products, Inc. will correct any such failure by either replacing or repairing any defective goods, at Keene Building Products, Inc.'s option.

The preceding paragraph sets forth the exclusive remedy for all claims based on failure of or defect in the goods sold hereunder, whether such failure or defect arises before or during the warranty period and whether a claim, however instituted, is based on contract, indemnity, warranty, tort (including negligence), strict liability or otherwise. The forgoing warranty is exclusive and is in lieu of all other warranties whether written, oral, implied or statutory.



P.O. Box 241353
Mayfield Heights, OH 44124
Info@KeeneBuilding.com
www.KeeneBuilding.com

877 | 514 | 5336
P 440 | 605 | 1020
F 440 | 605 | 1120

2/2
2015/1